
Operating pressure  $p_{max} = 500 \text{ bar}$ Flow Q<sub>max</sub> = 120 lpm

## 1. General

Orifices are the most simple version of a flow valve, which are designed to influence mainly the flow (acc. to DIN ISO 1219-1). The employed effect is based on the physical flow law  $\Delta p = (a Q)^m$ . With usually m = 2 for sharp edged, viscosity effect minimizing, orifices. The calculation constant a copes for shape related back pressure constants as well as conversion factors for the differing dimensions; ∆p (bar) and Q (lpm). This figure is evaluated best via tests (Δp-Q-curves).

These orifices are mainly employed to restrict the flow during shifting operations (e.g. increased shifting time, protection of pilot valve from excessive flow, in accumulator circuits, prevention of undesired side effects of shifting operations at directional valves with negative overlap etc.), see also D 7300. They are usually installed in hydraulic valves intended for manifold mounting. The throttle dimensions exactly fit in the port P of directional seated valves acc. to D 7300.

Symbol, mounting position



## 2. Available versions, main data

EB 2 -1,7 Order example:

Orifice insert	Pressure p <sub>max</sub>	Flow Q <sub>max</sub>	Orifice Ø (mm)												
	(bar)	(lpm)	- 0,4	- 0,6	- 0,8	- 1,0	- 1,2	- 1,7	- 2,1	- 2,5	- 3,0	- 3,5	- 4,0	- 4,2	
EB 0	500	6		•	•	•	•								
EB 1	700	10	•	•	•	•									
EB 2	700	40					•	•	•						
EB 3	500	100								•		•		•	
EB 4	500	120									•		•		

Nomenclature Orifice insert

Installed position Any

Mass (weight) EB 1 | EB 2 | EB 3 | EB 4 Type 10 g 18 g 6 g

Pressure fluid Hydraulic oil acc. to DIN 51524 table 1 to 3; ISO VG 10 to 68 conf. DIN 51 519

Viscosity range: min. approx. 4; max. approx. 1500 mm<sup>2</sup>/sec; Optimum: 10 to 500 mm<sup>2</sup>/sec

Also suitable are biologically degradable pressure fluids type HEES (synth. Ester) at operation tempe-


ratures up to approx. +70°C.


Temperatures Ambient: approx. -40...+80°C; Fluid: -25...+80°C, pay attention to the viscosity range!

Start temperature down to -40°C are allowable (Pay attention to the viscosity range during start!), as long as the operation temperature during subsequent running is at least 20K higher. Biological degradable pressure fluids: Pay attention to manufacturer's information. With regard to the compatibility with

sealing materials do not exceed +70°C.

∆p-Q-curve





Oil viscosity during

the test approx. 60 mm<sup>2</sup>/sec

> HAWE HYDRAULIK SE STREITFELDSTR. 25 • 81673 MÜNCHEN

D 6465


© 1971 by HAWE Hydraulik

Orifice inserts type EB..


February 2000-02

## 3. Unit dimensions, mounting holes


All dimensions in mm, subject to change without notice!



Type EB 4-...



Ongoing bore Ø20



O-rings 23.47x2.62 NBR 90 Sh

Z = Sharp edged but deburred, all other bores with chamfer 0.2 mm  $\varnothing$ d = Orifice (sect. 2)

**Attention:** O-rings are not scope of delivery and have to be ordered additionally!

## Notes regarding installation:

The exact fixation of the orifice insert in the housing takes place by plastic deformation of the surrounding material at the marked annular section during tightening of the mounting screws. This procedure makes housing bodies made of material with yield ability necessary i.e. all usual materials for hydraulic valves is fine excluding hardened or other material with extreme strength.

